

Care & Maintenance of Harfield Polycarbonate Tableware

Harfield polycarbonate products will give outstanding service providing the following points are observed:

- Never place the tableware near or on direct heat. For instance, do not put inside or on electric or gas cookers.
- Warming cupboards are usually safe for warming polycarbonate as long as they have no hot spots and do not exceed 85°C. Avoid warming for more than 60 minutes.
- Harfield polycarbonate tableware is microwave safe for reheating, but not for cooking food.

DO NOT USE BLEACH OR ABRASIVES OF ANY KIND, i.e. SCOURING PADS, SCOURERS, CLEANING POWDERS OR LIQUIDS.

CLEANING INSTRUCTIONS

- Harfield polycarbonate tableware is dishwasher safe and suited to hand washing and sterilising sinks. **Sterilising sinks should not exceed 85°C.**
- Maximum dishwasher temperatures should be 60°C - 65°C for the wash and 70°C - 85°C for the rinse. Higher temperatures may cause deterioration of the material.
- Some dishwasher detergents/rinse aids may cause stress cracking to polycarbonate tableware.
- Washing in hot soapy water should prevent any build up of discolouration.
- Milton Sterilising Fluid may be used to remove discolouration.

Please refer to
our **Tray Care &
Maintenance
Leaflet** for details
on cleaning your
trays.

Antibacterial Tableware - Please wash thoroughly before use to ensure full effectiveness of this product.

IT IS ESSENTIAL THAT YOUR DETERGENT AND RINSE AIDS ARE COMPATIBLE WITH POLYCARBONATE AND THAT THE CORRECT DOSAGES ARE USED. USING TOO MUCH OR LEAVING TABLEWARE TO SOAK FOR LONG PERIODS CAN SHORTEN THE LIFE OF THE PRODUCT.

Always check detergent/rinse aid/sanitiser compatibility and the correct dosages with your detergent supplier. All detergents should preferably have a pH value of below 10, ideally 7 or 8.

- Avoid contact with strong acids.
- Some food products with a high sugar content (approx. 10% or more) may require a little extra care when cleaning due to potential surface food deposits. Do not use scourers to remove.

Hand Wash Detergents

Do not use bactericidal detergents when washing polycarbonate tableware as this may cause deterioration of the material. Always check suitability of the hand wash detergent with the detergent manufacturer.

Harfield Hi Heat Range

Our new range of Hi Heat tableware is suitable for use up to +140°C.

- Please follow the polycarbonate tableware cleaning instructions.
- Oven safe as well as microwave and dishwasher safe to maximum +140°C.
- Do not apply to direct heat.
- The bowls can be stored in freezers for pre-prepared meals, but please note they are not suitable for direct transfer from freezer to



Harfield 180C Range & Oven To Tableware



The 180C Range & Oven to Tableware range are made from a high performance materials suitable for cooking, steaming, serving and freezing. With its excellent resistance to sudden extremes of temperature, they are also suited to blast freezing/chilling. Operating temps: Min -40°C to Max +180°C (for the 180C Range) and to +220°C (for the O2T Range).

- Not suited for use on induction or electric hobs, grills or direct flame of gas ovens as temperatures may exceed the max recommended.
- Can be used on heated surfaces as long as the max temperatures are not exceeded.

CARING FOR YOUR 180C RANGE AND OVEN TO TABLEWARE

- Our containers are robust and chip resistant, but are not unbreakable. Avoid dropping the containers on their rim, especially when full and removing from the freezer.
- These ranges warm up and cool down rapidly, so products may be hand held within minutes of removing from the oven and transferring to service.
- Avoid use of sharp metal knives which may result in surface scratches on your tableware. Use of a non metal utensil is recommended for portioning and serving food.
- Containers may be stacked to save space. Appropriate food content/date labels can be used without leaving residue.
- Please follow the cleaning instructions for polycarbonate tableware to wash your containers.

Harfield Polypropylene Range



- Maximum wash temperature 65°C.
- Large flat polypropylene trays may warp in dishwasher – we recommend handwashing.
- Do not apply to direct heat.
- Not safe for use in ovens or direct heat.
- Can be used for hot drinks such as tea and coffee.
- Microwave safe. Please note microwaving foods such as curry or other tomato based sauces may result in discolouration.
- Strong coloured food may also discolour polypropylene products.
- Freezer safe. As with all plastics, items stored in a freezer should not be dropped as this will cause them to break.